
How To Drain Your Sprinkler System



- Turn off your water at the dedicated Sprinkler Line Shut Off (A) in your basement/crawlspace.
- Open the 2 Petcock's (F) with a flat head screwdriver so that the screw head runs a 45 degree angle.
- Open you Inside Drain (B) to drain your system. Make sure to have a bucket available for water drainage. Total water drained may be a few cups to a few gallows depending on the length of the pipe.
- Open 2 Ball Valves (C & D) on backflow preventer (outside) to a 45 degree angle. DO NOT
 close off ball valves during freezing conditions, ALWAYS leave at a 45 degree angle to prevent
 trapping water.
- 5. Run your sprinkler timer through one manual cycle to release any water left in valves/system.
- For added protection, you may wrap an old towel/blanket around the backflow preventer.
 Always cover with a plastic bag to keep dry.

WARNING: Your sprinkler system still needs to be properly blown out or winterized to protect it against any deep freezes that may occur.

